



UNIVERSAL

KAYAK CARRIER KIT

2 NON-SKID
FOAM BLOCKS

2 BOW & STERN CAMBUCKLE
STRAPS WITH BUMPER HOOKS

1 15' CENTER STRAP
W/ CAMBUCKLE

2 9' BLOCK
STRAPS

1 REUSABLE
MESH BAG



**SATISFACTION
GUARANTEED***

**NON-SKID
BLOCKS**

Eliminate slippage between
wet car surface and block.

**HASSLE-FREE
INSTALLATION**

Cam buckle straps for
easy strapdown.

 **888-222-2191**

1700 W Big Beaver, Suite 150, Troy, MI 48084

www.envirolite.com

© 2014 Envirolite, LLC. All rights reserved.

*If you are not fully satisfied with your purchase, return your order within ten (10) days of receipt for a full refund.

KAYAK CARRIER KIT

INSTRUCTIONS

1 LASHING BLOCKS TO KAYAK

Unroll the 9' straps. Run each one of the straps through the slit on each block, wrap completely around kayak and buckle tightly. Both blocks should be secure to kayak.

2 LOADING KAYAK

Load kayak on car (cockpit-up) centered on roof. Reposition blocks if necessary, so that weight is evenly distributed on each pad. **IMPORTANT!** Make sure bottom of blocks and area of roof under blocks are clean and free of debris. On rainy days, be sure to cover exposed cockpit. Locate blocks as close to front and rear of car roof as possible.

3 OVER-THE-TOP STRAP

Unroll 15' center strap. Open car doors on each side. Throw non-buckle end of center strap over middle of kayak, letting the end hang down on either side of the car. Pull the strap tight and run the ends through open doors on eitherside of the car.

4 SECURING FRONT AND BACK

- A. Starting at the front of your car, take the strap with hook and cambuckle and place hook into towing loop or frame located at each end underneath car bumper. Repeat with hook strap (without buckle).
- B. Take strap (with cambuckle) and bring cambuckle end up to front of kayak and wrap around carry handle twice with cambuckle hanging down towards the ground. **(If your craft does not have a carry handle; use a piece of rope and make a loop attached to the end of craft).** Take strap (without buckle) from opposite end of bumper and bring it up and through the hanging cambuckle. Pull it down until you see tension and foam blocks compressing. **IMPORTANT!** Make sure no part of the kayak contacts car roof. Repeat the above procedure on the opposite end of the kayak.

5 IMPORTANT USE & CARE TIPS

Limit transport distance to 250 miles. Clean block and roof surfaces before use. Check block and roof surfaces before use. Check strap tension frequently. Keep straps away from exhaust system and sharp or abrasive surfaces. Protect painted surfaces from strap vibration.

6 SAFETY CHECK

After driving about five miles, stop and check to make sure straps are still tight and kayak is secure on top of car. Check to make sure no sharp or abrasive surfaces touch straps.

7 PREVENTING STRAP HUM

If straps hum or buzz at high speeds, give strap a few twists or fold sides of strap together and secure with tape or a shielded garbage tie. This breaks up wind vibration.

- ✓ FAST, EASY LOADING OF KAYAKS, SURFBOARDS AND SAILBOARDS
- ✓ NO TOOLS REQUIRED OR PERMANENT ATTACHMENTS NEEDED
- ✓ FOAM MOUNTING BLOCKS WILL NOT SCRATCH CAR

- ✓ HCFC/CFC FREE
- ✓ FITS ALL CARS
- ✓ MADE IN U.S.A.

 **888-222-2191**

1700 W Big Beaver, Suite 150, Troy, MI 48084

www.envirolite.com

© 2014 Envirolite, LLC. All rights reserved.